

1. Spread the arm evenly, make sure each arm is aligned with the center rod.
2. Attach the poly 1 on the nipple then secure by the loop.
3. Turn the nipple 2 into the coupler then secure by the hex nut.
4. Attach the cap on the nipple 2 then secure by the finial.
5. Attach the glass on the socket then secure by the socket ring.

