

Assembly Instruction For21264

- 1. Turn the nipple into the coupler then secure by the hex nut.
- 2. Attach the cap on the nipple then secure by the loop.
- 3. Turn the nipple 1 into the metal sheet.
- 4. Attach the cap 1 on the nipple 1 then secure by the ball 1.
- 5. Attach the cap 2 on the nipple 1 then secure by the ball 2.
- 6.Attach the glass on the socket then secure by the socket ring.

