



1. Remove the finial from the bottom cap.
2. Turn the I-bar left or right in order to take it out.
3. install the bulb (not include) into socket.
4. Put the I-bar in sideways.
5. The end of the I-bar must be in alignment with the slot of lamp frame until lock it.
6. Place the cap onto the thread of the I-bar and secure it with finial.
7. For more details, please see the assembly steps from back.

